

Patent Pending

# Slammer

Performance Docking Solutions

## INSTALLATION INSTRUCTIONS

### Recommended Tools:

- Level
- Cordless impact-drill with “Phillips” and “square drive” bits
- Measuring tape

### Installation Steps:

1. Determine where on the dock face you want your fender attached; ensure sufficient substructure available for securely fastening at least eight screws through track and into dock’s structure.
2. Pre-set 8-10 stainless steel screws into mounting track’s pre-drilled holes.
3. Align top of mounting track slightly below top edge of dock face or at the elevation desired.
4. Drive top center screw through mounting track and into dock face / substructure.
5. Level the mounting track and drive a second stainless screw. Check with level and then drive the remaining stainless screws ensuring screw heads are flush with mounting track’s face.
6. Holding the fender with bolt-ropes inboard; guide the bottom bolt-rope into the mounting track (approximately ½”) and then guide the top bolt-rope into the mounting track slide fender into place.
7. Insert one “square drive” stainless screw into the pre-drilled hole located at the center of the mounting track and aligned perpendicular to the top groove. This faster prevents lateral fender movement.
8. See our installation video at [www.SlammerMarine.com](http://www.SlammerMarine.com)

All of us on the shore crew thank you for choosing Slammer Marine Performance Docking Solutions.

**Please do not hesitate contacting us if you have any questions.**

[www.SlammerMarine.com](http://www.SlammerMarine.com)  
[info@slammermarine.com](mailto:info@slammermarine.com)  
(800) 295-3464